

Codeliste für Thomson TC99 Fernbedienung

Code: 001			
THOMSON	SABA	TELEFUNKEN	
M58	MB3003	FB0987	IMC4
M70	RCT8000Z	FB110	IMC500
RC3016	ST85	FB1120	IMC501
RC7000	TC1094	FB1122	IMC502
RC7000S	TC1095	FB120	IMC503
RCTK100	TC200	FB121	IMC5F
RCT2000	TC202	FB123	IMC5FTT
RCT2010	TC205	RC1121	IMC5M
RCT2020	TC294	RC1123	IMC5MTT
RCT2070	TC295	RC1124	IMC6
RCT2075	TC3000	RC11260Z	IMC60
RCT300	TC304	RC1127	IMC605
RCT3000	TC408	RC1130	IMC62
RCT3002	TC415	RC1132	IMC62/105
RCT3003	TC416	RC1140	IMC625
RCT3004	TC4165	RC1142	IMC63
RCT3006	TC416X	RC1143	IMC64
RCT3016	TC417	RC1341	IMC66
RCT500	TC418	RC1356	IMC7
RCT501	TC419	RC1361	IMC7TOP
RCT502	TC470	U6	IMC7TT
RCT503	TC471	U7	IMC702
RCT5000T	TC480	BRANDT	IMC7TOPTT
RCT5070	TC480S	M58	IMC8
RCT6000	TC481	M65	IMC8TOP
RCT7000	TC500	M70	IMC9TOP
RCT702	TC600	NORDMENDE	IMC9TOPTT
RCT712	TC1096	CMC2	IMC9TT
RCT8000	TC3003	IMC10P	IMCK100
RCT8000P	UTC1	IMC10TT	MC8
RCT80045	FERGUSON	IMC10Z	RCTK100
RCTK100-03	RHT10	IMC14	RCT8000P
T125	RHT30	IMC2	RCTK100-03
TC73	F1002	IMC3	
TC93	F3003		
TC97			
Code: 002			
FB1330	RC1345	RC1360	FB1330TOP
FB1330S	RC1346	RCT1355	RC345
RC1131	RC1350	FB330	RC1340
RC1141	RC1351	FB340	TC94
Code: 003			
M50	FB1185F	RCT5020	TC237
M52	FB181	RCT5121	TC4871
ST54	FB185	RCT5141	TC53
RCT3642	FB100F	ST45	
TI10	TI40/41	MT25	
MT24	TI45	TC460	